

80\*105mm

### BAMBOO WEATHER STATION INSTRUCTIONS

Remove protective sheet from LCD display area  
Insert 2 AAA batteries

#### Function:

1. The item displays 12/24 hours, year/month/day, temperature and humidity
2. The item displays a smiley face or sad face according to changes in temperature and humidity
3. Temperature range: -4°F To 158°F (-20°C to 70°C)
4. Humidity range: 20%RH to 95%RH

#### Instructions:

**Temperature:** Press the down button to switch between F or C.

**Time:** Press **SET** until the hour blinks. Use the up/down button to adjust the hour. Press **SET** again to adjust minutes. Use up/down button. Then press **SET** again to lock in. To adjust between 12/24 hour, press the up button.

**Date:** After setting time, press **SET** again to adjust year. Use up/down button. Press **SET** again. Adjust month/day using up/down button. Press **SET** once again to lock everything in.

#### Facial Display:

A smiley face is displayed when the temperature is between 68°F and 86°F (20°C and 30°C) and the humidity is between 40% and 70%.



A sad face is displayed when the temperature is below 68°F or above 86°F (20°C and 30°C) and the humidity is below 40% or above 70%.

